

Remark:

1. SXP5000 apply all devices(not only laptops) if device power require under 90W and connectors fit.
2. We choosed No 1,2,3,4,6,8,9,10,11,15,37,38 connectors. So here just listed these connectors.
3. Some models maybe missing here, not mean can't apply.

No 01 Connector 6.5*4.3/4.4mm, DC16V 3.36A/3.42A/3.75A/4A, Fit for Sony/Fujitsu models

Sony Vaio

VGP-AC19V39 VGP-AC19V47

PCG-4A1L PCG-4B1L PCG-4F1L PCG-4F2L PCG-4G1L PCG-4G2L PCG-4H2L PCG-4J1L PCG-4K1L PCG-4L1L
 PCG-4L2L PCG-4L3L PCG-4N1L PCG-4N2L PCG-4N3L PCG-4N4L PCG-4Q1L PCG-4Q3L PCG-4Q4L PCG-4R1L
 PCG-4R2L PCG-51AL PCG-531A PCG-532A PCG-5A1M PCG-6B1L PCG-6B2L PCG-6C1L PCG-6C2L PCG-6C3L
 PCG-6N2M PCG-X505ZP PCG-V505 CTO SONY VAIO PCG-321A PCG-322B PCG-325A PCG-431L PCG-432L
 PCG-441L PCG-461L PCG-462L PCG-462M PCG-481L PCG-481M PCG-491L PCG-492L PCG-500 PCG-505 PCG-551L
 PCG-561L PCG-571 PCG-581 PCG-582M PCG-591L PCG-661 PCG-671L PCG-672 PCG-681L PCG-682L PCG-691L
 PCG-705 PCG-711 PCG-833L PCG-873M PCG-881 PCG-882L PCG-883L PCG-884L PCG-885L PCG-3102 PCG-3112
 PCG-3122 PCG-3192 PCG-3212
 SVE141111I SVF142C29I SVF14n13CXB SVF14N13CX

Fujitsu PenCentra 130 200 Series

No 02 Connector 6.5*4.3/4.4mm, DC19.5V 4.7A, Fit for Sony/Fujitsu models

Sony Vaio:

PCG-F PCG-FR PCG-FX PCG-FXA PCG-GRS PCG-GRV PCG-GRX PCG-GRZ PCG-K PCG-NV PCG-QR PCG-R505
 PCG-R600 PCG-X PCG-XE PCG-XG PCG-XR -Z505 PCG-Z600

VGN-A VGN-AR VGN-BZ VGN-CR VGN-CS VGN-E VGN-FW VGN-FZ VGN-K VGN-NR VGN-NS VGN-NS VGN-NW
 VGN-SR VGN-TX VGN-Z VPCB

VPCCA VPCCB VPCE VPCEA VPCEA VPCEB VPCEC VPCEE VPCEFVPCEG VPCEH VPCEJ VPCEL VPCS VPCZ

SVE11 SVE14 SVE15 SVE17 SVF14 Fit SVF14 Fit E SVF15 Fit SVF15 Fit E SVS13 SVS15 SVT14 SVT15 VPCSA
 VPCSB VPCSE Series

ADP-45UD C ADP-75UB A ADP-75UB B ADP-90YB B PCGA-AC19V PCGA-AC19V1 PCGA-AC19V10

PCGA-AC19V11 PCGA-AC19V12 PCGA-AC19V13 PCGA-AC19V14 PCGA-AC19V19 PCGA-AC19V2 PCGA-AC19V20
 PCGA-AC19V21 PCGA-AC19V21 PCGA-AC19V23 PCGA-AC19V24 PCGA-AC19V25 PCGA-AC19V26 PCGA-AC19V27
 PCGA-AC19V28 PCGA-AC19V3 PCGA-AC19V4 PCGA-AC19V5 PCGA-AC19V6 PCGA-AC19V9

VGA-AC19V10 VGA-AC19V11 VGP-AC19V1 VGP-AC19V10 VGP-AC19V11 VGP-AC19V12 VGP-AC19V13
 VGP-AC19V14 VGP-AC19V15 VGP-AC19V19 VGP-AC19V2 VGP-AC19V20 VGP-AC19V21 VGP-AC19V22
 VGP-AC19V23 VGP-AC19V24 VGP-AC19V25 VGP-AC19V26 VGP-AC19V27 VGP-AC19V28 VGP-AC19V29
 VGP-AC19V3 VGP-AC19V30 VGP-AC19V31 VGP-AC19V32 VGP-AC19V33 VGP-AC19V34 VGP-AC19V35
 VGP-AC19V36 VGP-AC19V37 VGP-AC19V38 VGP-AC19V4 VGP-AC19V41 VGP-AC19V42 VGP-AC19V43
 VGP-AC19V44 VGP-AC19V8 VGP-AC19V48 VGP-AC19V49 VGP-AC19V60 VGP-AC19V61 VGP-AC19V62

SVE14118FXW SVE14A25CXS SVE14A290X SVE14112FXB SVE14112FXP SVE14112FXW SVE14114FXB
 SVE14114FXW SVE14116FXB SVE14116FXP SVE14116FXW SVE14117FXB SVE14118FXB SVE14118FXP
 SVE141190X SVE1411BFXP SVE1411BFXW SVE1411CFXW SVE1411DFXB SVE1411DFXP SVE1411DFXW
 SVE1411EGXB SVE1411JFXP SVE1411MFXB SVE1411MFXP

SVE15112FXS SVE15113FXS SVE15114FXS SVE15115FXS SVE151190X SVE1511AFXS SVE1511BGXS
 SVE1511CFXS SVE1511DFYS SVE1511GFXW SVE1511HFXW SVE1511JFXW SVE1511KFXW SVE1511MFXS
 SVE1511NFXS SVE1511PGXS SVE1511RFXB SVE1511RFXW SVE15122CXB SVE15122CXP SVE15122CXW
 SVE15124CXP SVE15124CXS SVE15124CXW

SVE17122CXB SVE17125CXB SVE17127CXB SVE171290X SVE1712ACXB SVE1712BCXB SVE17132CXB
 SVE17135CXB SVE17137CXB SVE171390X SVE1713ACXB SVE1713ACXBC SVE1713BPXB SVE1713CCXB
 SVE1713DCXB

SVS13112FXB SVS13112FXP SVS13112FXS SVS13112FXW SVS13115FXB SVS13115FXS SVS13118FXB
 SVS131190X SVS1311AGXB SVS1311BFXW SVS1311CGXB SVS1311DGXB SVS1311ZDZB SVS13122CXB

SVS13122CXP SVS13122CXR SVS13122CXS SVS13122CXW SVS13125CXB SVS131290X SVS1312ACXP
SVS1312ACXW SVS1313AGXB SVS1313BGXB

SVS15113FXB SVS15113FXS SVS15115FXB SVS15116FXB SVS15116FXS SVS15118FXB SVS151190X
SVS1511AGXB SVS1511BFXB SVS1511CFXB SVS1511DGXB SVS1511EGXB SVS1511GFYB SVS1511HGXB
SVS15123CXB SVS15123CXS SVS15125CXB SVS15125CXW SVS151290X SVS1512ACXS SVS1512EPXB
SVS1512GPXB SVS1513AGXB SVS1513BGXB

SVT13112FXS SVT13113FXS SVT13114GXS SVT13116FXS SVT13118FXS SVT131190X SVT1311CGXS
SVT1311EFYS SVT13122CXS SVT13124CXS SVT13125CXS SVT13126CXS SVT13126CYS SVT13127CXS
SVT13128CXS SVT13128CYS SVT131290X SVT1312BPXS SVT13132CXS SVT13132PXS SVT13134CXS
SVT13135CXS SVT13136CXS SVT13136CYS SVT13137CXS SVT13138CXS

SVT14112CXS SVT14113CXS SVT14115CXS SVT14117CXS SVT141190X SVT14122CXS SVT14122PXS
SVT14124CXS SVT14125CXS SVT14126CXS SVT14127CXS SVT141290X SVT1412ACXS

SVT15112CXS SVT15114CXS SVT15114CYS SVT15115CXS SVT15117CXS SVT151190X SVT1511ACXS

VPCCA17FX VPCCA190X VPCCA22FX VPCCA23FX VPCCA25FX VPCCA290X VPCCA2SFX VPCCA390X VPC-
CA3AFX

VPCCB17FX VPCCB190X VPCCB22FX VPCCB23FX VPCCB25FX VPCCB27FX VPCCB290X VPCCB2AFX VPC-
CB2SFX VPCCB390X VPCCB3AFX VPCCB490X VPCCB4SFX

VPCCW13FX VPCCW14FX VPCCW15FX VPCCW17FX VPCCW18FX VPCCW190X VPCCW19FX VPCCW1PFX
VPCCW21FX VPCCW22FX VPCCW23FX VPCCW26FX VPCCW27FX VPCCW290X VPCCW2DGX VPCCW2FGX
VPCCW2JGX/B VPCCW2PFX VPCCW2QGX

VPCS111FM VPCS131FM VPCS132FX VPCS132GX VPCS134GX VPCS135FX VPCS137GX VPCS1390X
VPCS13AGX VPCS13CGX VPCS13DGX VPCS13EGX VPCS13GGX VPCS13HGX VPCSB31FX VPCSB390X
VPCSB3AFX VPCSB490X VPCSB4AFX VPCSC1AFM VPCSC1AFMS VPCSE290X VPCSE2DGX VPCSE2EFX
VPCSE2KGX VPCSE2MFY VPCSE2SFX

VPCW111XX VPCW121AX VPCW211AX VPCW212AX VPCW215AX VPCW221AX VPCW222AX

VPCY115FX VPCY118GX VPCY216FX VPCY216GX VPCY218FX VPCY2190X VPCY21AFX VPCY21EFX VPCY21SFX
VPCYB13KX VPCYB14KX VPCYB15KX VPCYB15KXS VPCYB33KX VPCYB35KX

VPCZ112GX VPCZ114GX VPCZ116GX VPCZ1190X VPCZ119GX VPCZ11CGX VPCZ2190X VPCZ21AGX VPCZ21BGX
VPCZ21CGX VPCZ21DGX VPCZ21SHX VPCZ21TGX VPCZ21ZDZ VPCZ2290X VPCZ22AGX VPCZ22SHX
VPCZ22TGX VPCZ22UGX VPCZ2390X

VPCEA21FX VPCEA22FX VPCEA24FM VPCEA25FX VPCEA27FX VPCEA290X VPCEA2JFX VPCEA31FX
VPCEA33FX VPCEA36FM VPCEA36FMW VPCEA36FX VPCEA390X

VPCEB11FM VPCEB11FX VPCEB11GX VPCEB12FX VPCEB13FX VPCEB14FX VPCEB15FM VPCEB15FX
VPCEB16FX VPCEB17FX VPCEB190X VPCEB1KGX VPCEB1LFX VPCEB1SFX VPCEB23FM VPCEB23FX

VPCEC22FX VPCEC25FX VPCEC290X VPCEC390X VPCEC3AFX VPCEC3BFX VPCEC3CFX VPCEC3DFX
VPCEC490X VPCEC4BFX VPCEC4CFX

VPCEE21FX VPCEE22FX VPCEE23FX VPCEE25FX VPCEE26FX VPCEE31FX VPCEE32FX VPCEE33FX
VPCEE34FX VPCEE35FX VPCEE37FX VPCEE3WFX VPCEE41FX VPCEE42FX

No 03 Connector 6.3*3.0mm, DC15V 3A/4A/5A, Fit for Toshiba/NEC models

Toshiba Tecra A6 A7 A8 A9 A10 F Satellite 1400 Series Satellite 1800 Series

No 04 Connector 5.5*2.5mm, DC16V 4.5A, Fit for IBM/Lenovo models

Lenovo 08K8206 08K8207 08K8208 08K8209 08K8210

No 05 Connector 5.5*2.5mm, DC19V 3.16A/3.42A/4.74A, Fit for HP/Acer/Toshiba/Dell/Lenovo/Asus/NEC/Delta/IBM Compaq/Fujitsu models

Toshiba Satellite 1100-S101 1105; 1110: 1110-S153; 1115: 1115-S103 1115-S104 1115-S107 1115-S123; 1130: 1130-S155 1130-S156; 1135: 1135-S125 1135-S155 1135-S156 1135-S1551 1135-S1552 1135-S1553 1135-S1554; 1900: 1900-S305; 1905: 1905-S277 1905-S301 1905-S302 1905-S303 1905-S304 1905-S801; 1950; 1955: 1955-S801 1955-S802 1955-S803 1955-S804 1955-S805 1955-S806 1955-S807; 2430: 2430-SB 2430-S255 2430-S256; 2435: 2435-S255 2435-S256; A105 A135 A205 A215 A305 A505 A665 A665-S5170

Asus X401 X401A X401U X44 X44H X450 X450L X450LB X450LC X45 X455 X455L X455LA X455LF X501 X501A X502 X502C X502CA X51 X52F X53 X53E X54 X54L X55 X55C X550 X550C X550CA X550J X550JK X550L X550LA X550Z X550ZA X551 X551C X551CA X551M X551MA X552 X552C X552E X552EA X552L X552LA X555 X555C X555CA X555D X555DA X555L X555LA X555LB X555U X555Y X555YA X705 X705MA X75A X751 X751L X751LX X751M X751MA X751N X751NA X751S X751SA; R503U R510 R510C R510CA R510D R510L R510LA R554 R554L R554LA R556 R556L R556LA; S300 S300C S300CA S301 S301L S301LA S400 S400C S400CA S46 S46CA S500 S500C S500CA S551 S56 S56C; F550C F551 F551C F551CA F551M F552C F554 F554L F554LA F555 F555L F555LA F555U F555UA; TP500 TP500L TP500LA TP550 TP550L TP550LA; K50I K52F K53E K53U K55A K550 K550C K550CA K550L K550LA K551 K551L K551LN; D550 D550M D550C; P/N AD883020 AD887020 AD887320 ADP-65BW B ADP-65AW A ADP-65DW B ADP-65DW C ADP-65GD B ADP-65JH BB EXA1203YH EXA1208EH PA-1650-78 PA-1650-93 PA-1700-02 W15-065n1b

No 08 Connector 4.8*1.7mm, DC18.5V 3.5A/4.9A, Fit for NEC/Delta/Acer/Compaq/HP/Asus/LG models

HP Folio 13; Pavilion DM3 DM3t DM3z DV2000 Dv2000t DV2100 DV2200 DV2214us Dv2415 Dv2718us DV2800 DV2900 DV4000 DV5000 DV5000z DV6000 DV6100 DV6200 Dv6300 DV6400 DV6500 DV6700 Dv6701 Dv6702 Dv6703 Dv6704 DV6800 Dv6815ed DV6900 DV8000 DV8100 DV8300 DV8380us DV9000 DV9005 DV9010 DV9100 DV9200 DV9300 DV9400 DV9500 DV9700 Dv9700t Dv9700z Dv9715nr Dv9720us DV9800 DV9900 Dx6697us Tx1300 Tx1400 Tx1499us Tx2110 Tx2120 Tx2130 Tx2140; Pavilion TouchSmart 14-B109TX 14-B109WM 14-B150US 14-B157NR 15-B104XX 15-B119WM 15-B123CL 15-B129CA 15-B129WM 15-B156NR 15-B161NR 15-B189CA; Chromebook 14-C000 14-C010US 14-C011NR 14-C015DX 14-C020US 14-C025US 14-C030US 14-C035US 14-C050NR 14-C050US 14-C053CL 14-c000ed14-c000; ENVY 4/6 Series; ENVY SLEEKBOOK 4/6/14 Series

No 09 Connector 7.4*5.0mm with pin, DC19.5V 2.31A/3.34A/4.62A, Fit for Dell models

Dell Precision M1210 M140 M20 M60 M65 M70; Vostro 1000 1014 1015 1088 1220 1310 1320 1400 1440 1500 1510 1520 1540 1700 1710 1720 2420 2510 2520 3300 3350 3360 3400 3460 3500 3555 3560 A840 A860 E5400 E5404 E5410 E5420 E5430 E5440 E5450 E5470 E5480 V13 V130; XPS L421X M1210 M1330 M1530 18 1810; Inspiron 11Z/12/13Z/14/14R/15/15R/15Z/17/17R/17Z Series: 1121 1564 1570 1720 1750 1764 5323 3420 3437 3442 3443 5420 5421 5423 5437 3520 3521 3531 3537 3542 3721 3737 5520 5521 5537 5720 5721 5737 6430U 7204 7420 7520 7537 7737 E6230 E6430 E6430ATG E6430S E7250 E7470 N5110 N7010 N7110;

Latitude 12/14 Series: 3150 3330 3340 3350 3380 3440 3450 3480 3540 3550 5290 2 In 1 6400 7389 2-in-1 9300 E1405 E1505 E5250 E5440 E5450 E5500 E5500n E5510 E5510n E5520 E5520m E5530 E5540 E5550 E6220 E6320 E6330 E6440 E6540 E7240 E7270 E7440 E7450 M101z M4110 M5030 N5010 N5030 N5040 N5050 Rugged Extreme 7212, Rugged 5404, Rugged Extreme 7404 7414; P/N 310-2860 310-2862 310-3149 310-3399 310-4002 310-6325 310-6557 310-7712 310-7866 310-8363 310-9048 310-9249 310-9438 5U092 9T215 928G4 A00008 AA22850 DA65NM111-00 DF263 F7970 FA65NE1-00 HA65NS-00 HF991 LA65NE1-00 LA65NS2-01 MK911 N2765 NADP-90KB PA-12 PA-1900-02D PA-2E PC531 XD733 XD802 YR733

Dell Latitude 7480 5480 7280 N5110 5580 7214 5404 5414 7414 2100 2110 2120 3150 3160 3190 3300 3330 3340 3350 7390 3380 3450 3470 3480 3540 3550 3580 5250 5270 5420 5470 5500 6430u E5250 E5270 E5430 E5410 E5500 E5440 E5450 E5470 E5480 E5540 E5550 E5570 E5580 E6230 E6410 E6430 E6430 ATG E6430s E6440 E6510 E6520 E6530 E7240 E7250 E7270 E7280 E7440 E7450 E7470 E7280 7400 7404 Chromebook 11 3120 3180 3189 730-8301 CB1C13 730-8302 Touchscreen 11" 11.6" series

No 10 Connector 7.4*5.0mm, DC19.5V 2.31A/3.34A/4.62A, Fit for HP/Compaq models

HP Stream 11 13 14 X2 TouchSmart 15-n 15-f Spectre x360 360 x2 13 13t 15 PC HP 250 G3 G4 G5 G6 255-G4 245-g5 255-G5 255-G6 455-G3 PS 430 210-G1 ProBook 11 EE G1 210-G1 255-G3 255-G4 255-G5 340-G2 350-G2 355-G2

410-G1 450-G3 455-G3 612-G1 Probook 430 g3 g4 g5 EliteBook Folio 1020 G1 1040 G1 1040 G2 G1Q52UT F2R68UT F2R69UT F2R70UT F2R71UT F2R72UT HP Split 13 x2 13-g100 13-m000 x360 Pavillon x360 x2 11 11t 13 15 M3 m3-u001dx

HP Pavilion G6 G7 G4 DV4 DV5 DV6 DV6T DV7 DM4 M4 M6 G60 G62 G72 HP Envy DV4 DV7 M4 M6; HP Elitebook 2170p 2530p 2540p 2560p 2570p 2730p 2740p 2760p 6930p 8460w 430 440 450 455 G1 720 740 750 820 840 850

HP EliteBook Revolve 810 G1 G2 G3 HP ZBook 14 G1 G2, 4320s 4710s 4510s 4520s 4530s 4540s 5220m 5320m 5330m 6360b 6450b 6460b 6470b 6550b 6560b 6570b CQ32 CQ35 CQ36 CQ40 CQ41 CQ42 CQ72; HP 2000 Notebook PC 8425-001 693715-001 693713-001 693712-001 613160-001

No 11 Connector 5.5x1.7/2.1mm, DC19V 3.42A/4.74A, Fit for Acer models

Acer Aspire 1 3 5 E15 E14 E11 ES1 E5 E3 E1 F15 V15 VN7 V5 V3 V7 V5-131 V5-171 V5-431 V5-471P V5-472 E15 N15W4 E14 E11 ES1 E5 E3 E1 E17 F15 E5-553 E5-575 E5-575-33BM Timeline Ultra TravelMate Series

Gateway MD7818U MD7820U NE56 NE56R10U NE56R11U NE56R12U NE56R13U NE56R15U NE56R27U NE56R31U NE56R34U NE56R37U NE56R41U NE56R42U NE71B06U NV55C NV57H NV59 NV59C NV73 NV79 Q5WTC

No 15 Connector 7.9*5.4mm, DC20V 2.25A/3.25A/3.51A/4.5A, Fit for IBM/Lenovo models

Lenovo ThinkPad E

E220s E320 E325 E420s;

L330 L410 L412 L430 L420 L421 L510 L512 L520 L530; ThinkPad N Series: N100;

R60 R61; ThinkPad S Series: S230u S420 S430 SL300 SL400 SL410 SL410k SL500 SL510

T400 T410 T410i T410s T410si T420 T420i T420s T420si T430 T430i T430s T430si T500 T510 T510i T520 T520i T530 T530i T540p;

X100e X120e X121e X130e X131e X140e X1 Hybrid X200 X220T X201 X201i X201s X220 X220i X220t X220it X230 X230i X300 X60 X60s X61

Z60 Z60t Z61; Edge E10 E120 E125 E130 E135 E145 E30 E31 E330 E335 E40 E420 E420s E425 E430 E430(c) E435 E445 E50 E520 E525 E530 E530(c) E535 E545 S220; P/N FRU 92P1106, 92P1110, 92P1104, FRU 92P1108, 92P1111, FRU 92P1112, FRU 92P1114, FRU 92P1153, 92P1154, 92P1156, FRU 92P1157, 92P1158, 92P1159, 92P1160, 92P1161, 92P1211, 92P1212, 92P1255, 92P1253, 92P1254, 93P5026, 40Y7630, 40Y7659, 40Y7660, 40Y7661, 40Y7662, 40Y7663, 40Y7664, 40Y7665, 40Y7667, 40Y7668, 40Y7669, 40Y7670, 40Y7671, 40Y7672, 40Y7673, 40Y7674, 40Y7697, 40Y7698, 40Y7699, 40Y7700, 40Y7701, 40Y7702, 40Y7703, 40Y7704, 40Y7705, 40Y7706, 40Y7707, 40Y7708, 40Y7709, 40Y7710, 40Y7711, 42T5282, 42T5283, PA-1650-161, PA-1650-171, PA-1900-171

No 37 Connector 4.5*3.0mm, DC19.5V 2.31A/3.33A/4.62A, Fit for HP models

HP Pavilion Elitebook TouchSmart 725 745 755 820 830 840 850 G3 G4 G5 ProBook 430 440 450 455 470 640 650 G1 G2 G3 G4 G5 G6 G7 x360 Pavilion x360 Stream 11 Pro G3 G4 EE Chromebook 11 EE G2 G3 G4 G5 Spectre x360 x2 Folio Elitebook Folio 1020 1030 1040 G1 G2 G3 Zbook 14 14u 15u x2 G2 G 3 G4 series

No 38 Connector 11*5mm, DC20V 2.25A/3.25A/4.5A, Fit for Lenovo models

Lenovo ThinkPad X1 Carbon 1st 2nd 3rd 4th Generation ThinkPad X1 Yoga 1st Generation Yoga 2 11 11E 12 13 730-15 T T431s T440 T440p T440s T450 T450s T460 T460s T470 T470s T550 T560 T570 TP25 X X240 X240S X250 X260 X270 Z Z50 Z50-70 Z50-75 Z70 Z70-80 E E431 E440 E450 E455 E460 E465 E470 E475 E531 E540 E550 E550c E555 E560 E565 E570 E575 L L440 L450 L460 L470 L540 L560 L570 B B40-30 B50-30 B50-35 B50-70 B5400 S S431 S440 S531 S540 P40 Yoga P50S P51S W550S HELIX Edge 2 S41-70 IdeaPad 300 M73 M920Q V330 V330-151KB Flex 2 3 1120 1580 Flex 14 G G50 G50-45 G51-35 G500 series laptop charger AC adapter power supply cord